# 1. General Description

# A: SPECIFICATIONS


	Model	NON-TURBO	TURBO			
Clutch cover	Туре		Push type	Pull type		
	Diaphragm set load kgf (II		kgf (lb)	580 (1,276)	800 (1,764)	
	Facing material			Woven (Non asbestos)		
Clutch disc	O.D. × I.D. × thickness	mm (in)	Flywheel side	225 × 150 × 3.5 (8.86 × 5.91 × 0.138)	230 × 155 × 3.5 (9.06 × 6.10 × 0.138)	
			Pressure plate side		230 × 155 × 3.2 (9.06 × 6.10 × 0.126)	
	Spline O.D. mm (in)		25.2 (0.992), (No. of teeth: 24)			
Clutch release	e lever ratio	1.6	1.7			
Release bearing				Grease-packed self-aligning		
Clutch pedal	Full stroke mm (in)		130 — 135 (5.12 — 5.31)			
	Free play mm (in)			4 — 13 (0.16 — 0.51)	4 — 12 (0.16 — 0.47)	
Clutch disc	Depth of rivet head mm (in)	Standard		1.65 — 2.25 (0.065 — 0.089)	1.3 — 1.9 (0.051 — 0.075)	
		Limit of sinking		0.3 (0.012)		
	Limit for deflection mm (in)		0.8 (0.031) at R = 107 (4.21)	0.8 (0.031) at R = 110 (4.33)		

I.D.: Inner diameter O.D.: Outer diameter

# **B: COMPONENT**

# 1. CLUTCH ASSEMBLY

• NON-TURBO MODEL



- (1) Clutch release lever dust cover
- (2) Retainer spring
- (3) Pivot
- (4) Clutch release lever
- (5) Clip


- (6) Clutch release bearing
- (7) Clutch cover
- (8) Clutch disc
- (9) Flywheel

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 16 (1.6, 11.8)

T2: 72 (7.3, 52.8)

#### • TURBO MODEL




- (1) Clutch release lever dust cover
- (2) Clutch release lever
- (3) Clutch release lever shaft
- (4) Plug
- (5) Clutch release bearing
- (6) Clutch cover
- (7) Clutch disc
- (8) Flywheel

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 16 (1.6, 11.8) T2: 44 (4.5, 32.5) T3: 72 (7.3, 52.8)

# 2. CLUTCH PIPE AND HOSE

• NON-TURBO MODEL



- (1) Operating cylinder
- (2) Washer
- (3) Clutch hose
- (4) Bracket
- (5) Clip

- (6) Clutch pipe
- (7) Master cylinder ASSY
- (8) Clevis pin
- (9) Snap pin
- (10) Lever

# Tightening torque: N⋅m (kgf-m, ft-lb)


T1: 8 (0.8, 5.8)

T2: 15 (1.5, 10.8)

T3: 18 (1.8, 13.0)

T4: 37 (3.8, 27.5)

#### • TURBO MODEL



- (1) Operating cylinder
- (2) Washer
- (3) Clutch hose
- (4) Bracket
- (5) Clip

- (6) Clutch pipe
- (7) Master cylinder ASSY
- (8) Clevis pin
- (9) Snap pin
- (10) Lever

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 8 (0.8, 5.8)


T2: 15 (1.5, 10.8)

T3: 18 (1.8, 13.0)

T4: 37 (3.8, 27.5)

#### 3. MASTER CYLINDER

#### • NON-TURBO MODEL



- (1) Reservoir cap
- (2) Reservoir tank
- (3) Oil seal
- (4) Straight pin
- (5) Master cylinder
- (6) Clutch damper


- (7) Gasket
- (8) Return spring
- (9) Piston
- (10) Push rod
- (11) Piston stop ring
- (12) Cylinder boot

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 10 (1.0, 7)

T2: 46.6 (4.75, 34.4)

#### • TURBO MODEL




- (1) Reservoir cap
- (2) Reservoir tank
- (3) Oil seal
- (4) Straight pin
- (5) Master cylinder
- (6) Clutch damper

- (7) Gasket
- (8) Return spring
- (9) Piston
- (10) Push rod
- (11) Piston stop ring
- (12) Cylinder boot

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 10 (1.0, 7) T2: 46.6 (4.75, 34.4)

#### 4. CLUTCH PEDAL



- (1) Stopper
- (2) Bushing
- (3) Spring pin
- (4) Snap pin
- (5) Brake pedal pad
- (6) Brake pedal
- (7) Clevis pin
- (8) Brake pedal spring
- (9) Clutch pedal pad
- (10) Clutch pedal
- (11) Bushing C

- (12) Clutch clevis pin
- (13) Assist rod A
- (14) Clip
- (15) Assist spring
- (16) Assist bushing
- (17) Assist rod B
- (18) Spring S
- (19) Rod S
- (20) Bushing S
- (21) Clip
- (22) Clutch switch (With cruise control)

- (23) Stop light switch
- (24) Pedal bracket
- (25) Clutch master cylinder bracket
- (26) Lever
- (27) Clutch switch (Starter interlock)

Tightening torque: N⋅m (kgf-m, ft-lb)

T1: 8 (0.8, 5.8)

T2: 18 (1.8, 13.0)

#### C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Use SUBARU genuine fluid, grease etc. or the equivalent. Do not mix fluid, grease etc. with that of another grade or from other manufacturers.

- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Apply grease onto sliding or revolution surfaces before installation.
- Before installing O-rings or snap rings, apply sufficient amount of fluid to avoid damage and deformation
- Before securing a part on a vise, place cushioning material such as wood blocks, aluminum plate, or shop cloth between the part and the vise.
- Keep fluid away from the vehicle body. If any fluid contacts the vehicle body, immediately flush the area with water.

#### D: PREPARATION TOOL

#### 1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	498497100	CRANKSHAFT STOPPER	Used for stopping rotation of flywheel when loosening tightening bolt, etc.
ST-498497100			
	499747100	CLUTCH DISC GUIDE	Used when installing clutch disc to flywheel.
ST-499747100			

#### 2. GENERAL PURPOSE TOOLS

TOOL NAME	REMARKS		
Circuit Tester	Used for measuring resistance, voltage and ampere.		
Dial Gauge	Used for measuring clutch disk run-out.		