

GENERAL DESCRIPTION

LIGHTING SYSTEM

1. General Description

A: SPECIFICATIONS

| | | |
|-------------------------|----------------------------|------------------|
| Headlight | | 12 V — 55 W/60 W |
| Front turn signal light | | 12 V — 21 W |
| Clearance light | | 12 V — 5 W |
| Side marker light | | 12 V — 5 W |
| Front fog light | | 12 V — 55 W |
| Rear combination light | Tail/Stop light | 12 V — 5/21 W |
| | Turn signal light | 12 V — 21 W |
| | Back-up light | 12 V — 16 W |
| License plate light | | 12 V — 5 W |
| High-mounted stop light | Standard type | 12 V — 13 W |
| | Rear spoiler built-in type | 12 V — 1.2 W |
| Room light | | 12 V — 8 W |
| Spot light | | 12 V — 8 W |
| Luggage room light | | 12 V — 5 W |

B: PRECAUTIONS

- Before removing and installing parts, always disconnect the battery ground cable. When replacing radio, control module, and other parts provided with memory functions, record memory contents before disconnecting the battery ground cable. Otherwise, the memory will be erased.
- Reassemble in reverse order of disassembly, unless otherwise indicated.
- Adjust parts to the given specifications.
- Connect the connectors and hoses securely during reassembly.
- After reassembly, make sure functional parts operate smoothly.

WARNING:

- **Airbag system wiring harness is routed near electrical parts and switches. All airbag system wiring harnesses and connectors are yellow. Do not use electric test equipment on these circuits.**
- **Be careful not to damage the airbag system wiring harness when servicing electrical parts and switches.**

C: PREPARATION TOOL

1. GENERAL TOOLS

| TOOL NAME | REMARKS |
|----------------|--|
| Circuit Tester | Used for measuring resistance and voltage. |